VIZUALOGIC™



USER MANUAL

Elite Console

Center Armrest Monitor

With Adjustable Bracket

⚠ CAUTION:

Please Test All Functions Before Installing.

Contents

Operating Instructions
Welcome 2
Safety Instructions 2
CAUTION 2
WARNING 2
PRECAUTIONS 3

Getting Started
Monitor Function Overview 4
When Using Remote Control 5
Remote Control Battery Replacement 5
Remote Control Function Overview 5

Basic Operations
Before Using the MMD 7
Turning Power ON/OFF 7
Placing Discs 7
Switching Source 7
FM / IR 7

Monitor Setup
Adjusting OSD 7
- Adjusting Bright 7
- Adjusting Contrast 7
- Adjusting Color 7
- Adjusting Hue 7
- Resetting Picture Adjustment 7

MMD (Open Cover Multimedia Driver) Operations
Playing DVD/ VCD/ CD 8
Disc Auto Play 8
Stopping Playback (PRE-STOP) 8
Stopping Playback 8
Playing Still Frames (PAUSE) 8
Fast-forwarding / Fast-reversing 8
Finding the Beginning of Chapters 9
Setting Dimmer 9
Slow Motion Playback 9
Setting Zoom In / Out 9
Repeating Display Period (A-B) 9
Setting Random 9
Switching Angle (DVD Only) 9
Using Number Key Pad 9
Displaying Disc Status 10
Switching Subtitles (DVD Only) 10
Switching Audio Tracks 10
Chapter/ Track /Title Repeat Playback 10

USB Operations
Switching DVD / USB / Memory Card Mode 11
Setting Random 11
Repeat Playback 11

MMD Setup
DVD Setup Operation 12
General Setup Page 12
- Setting TV Display 12
- Setting OSD Language 13
- Setting Screen Saver 13
- Setting Last Memory 13

Password Setup Page 13
Preference Setup 14
- Setting TV Type 14
- Setting Audio Language 14
- Setting Subtitle Language 14
- Setting Disc Menu Language 14
- Setting Parental 14
- Setting Default 14

Installation and Connections
CAUTION 15
WARNING 15
PRECAUTIONS 15
Parts Indication 16
Limitation 17
Installation Steps 18
Connections 20
System Connections 21

Information
Accessories 22
General Specifications 23
Trouble Shooting 24
Warranty 25
Warranty Card 26

Welcome

- Thank you for purchasing the ELite Console Monitor. This manual will help you use the features of your new monitor.
- Please read all safety and operating instructions in this manual carefully, and keep this manual for future reference.

Safety Instructions

Please be sure to observe the following instructions and precautions to ensure safe using of this product. If anyone uses this product in a non-correct way and causes the product to be broke or damaged we will not be held responsible.

⚠ Caution:

This symbol means "Please be sure to observe." Failure to heed them can result in injury or material property damage.

Do not repair, alter or disassemble by yourself.
Doing so may result in an accident, fire or electric shock. Consult a retailer or service technician for inspections and repairs, if maintenance is needed.

Halt use immediatley if an Unusual state appears.
Failure to do so may cause personal injury or damage to the product. Return it to your authorized dealer or nearest service center for repairing.

Keep fingers from touching the Dvd optic eye when there is no Dvd in the player

Failure to do so may result in personal injury or damage to the product.

Do not strike or slam the monitor down.
Doing so may result in personal injury or damage to the product.

Do not leave the disc in the car or in the player for a long period of time.

Never expose the disc to direct sunlight. Heat and humidity may damage the disc and you may not be able to play it again.

Do not touch the pick-up head.

Failure to do so may result in damage to the product.



⊘ Warning:

This symbol means "Forbids this behavior." Failure to heed them can result in serious injury or death.

Do not operate any function that takes your attention away from safely driving your vehicle.
Any function that requires driver's prolonged attention should only be performed after coming to a complete stop. Always stop the vehicle in a safe location before performing these functions. Failure to do so may result in an accident.

Do not touch the screen if it has been cracked.
If the liquid crystal touches any part of your body, please wash your hands with soap and water immediatly. If irritation to the skin arrises contact a physician immediatly.

Do not expose the monitor to high humidity levels.
Failure to do so may result in fire or electric shock.

Do not expose this monitor to water or any liquid.
Doing so may result in electric shock or damage to the monitor.

Do not operate this monitor with wet hands.
Failure to do so may result in electric shock or damage

Do not use this monitor if the power cord has been damaged.
Doing so may result in fire or electric shock.

Use only in vehicles with A 12 Volt negative ground.
(Check with your dealer if you are not sure.)
If the product is used for anything other than it was designed for it could result in fire, or electric shock or other injury.

Keep small objects such as battereis out of the reach of children.
Swallowing them may result in serious injury.
If swallowed, consult a physician immediately.

Do not block vents or radiator panels.
Doing so may cause heat to build up inside and may result in fire.

Do not place hands, fingers or foreign objects in slots or gaps.
Failure to do so may result in personal injury or damage to the product.

Operating Instructions

Precautions

Please read all safety and operating instructions in this manual carefully, and keep this manual for future reference.

Temperature

- The back seat passenger must buckle the safety belt before operating this monitor.
- Do not insert the USB while driving. Failure to do so may result in personal injury.

Installation

Do not operate your unit in ambient temperature above + 50°C (+122°F) or below 0°C (+32°F).

Installation

- Please inquire your retail shop to contact your specialized engineer or technical staff for installation.
- Be sure to comply with this manual while connecting the cables. Failure to do so may result in damage to the product.
- Be sure the stability of the signal cable while installing. Failure to do so may cause fire or electric shock due to the wear of the signal cable.
- Be sure to collect the cables well after installation. Failure to do so may cause fire or electric shock.

Maintenance

If you have problems, do not attempt to repair the unit by yourself. Doing so may result in personal injury or damage to the product. Return product to you local reatil shop.

Characteristics of LCD Panel

- After turning the system off, a slight ghost of the image will remain temporarily. This is an effect peculiar to LCD technology and is normal.
- Under cold temperature conditions, the screen may lose contrast temporarily. After a short warm-up period, it will return to normal.
- The LCD panel is manufactured using an extremely high precision manufacturing technology. Its effective pixel ratio is over 99.99%. This means that 0.01% of the pixels could be either always ON or OFF.

Using the remote control

- Point the remote control at the remote sensors within 2 meters.
- It may not be possible to operate the remote control if the remote control sensor is exposed to direct sunlight or interferes with objects.

Product Cleaning

Use a soft dry cloth for periodic cleaning of the product. For more severe stains, please dampen the cloth with water only. Anything else has the chance of dissolving the paint or damaging the plastic.

Placing Disc

- Make sure the label side is facing you when you place the disc.
- Your player accepts only one disc at a time for play-back. Do not attempt to place more than one disc.
- Playing a disc while driving on a very bumpy road may result in skips, but this will not scratch the disc or damage the player.

Damage Disc

Do not attempt to play cracked, warped, or damaged discs. Playing a bad disc could severely damage the playback mechanism.

Irregular Shaped Discs

Be sure to use round shaped discs only for this unit and never use any special shaped discs. Use of special shaped discs may cause damage to the mechanism.

Correct Handling

- Do not drop the disc while handling.
- Hold the disc so you will not leave fingerprints on the surface.
- Do not affix tape, paper, or gummed labels to the disc.
- Do not write on the disc.
- Do not touch the surface.
- Do not expose the disc to direct sunlight.
- Clean the disc when it is dusty.
- Make sure that the disc is smooth and flat.
- Do not use commercially available disc accessories.



Disc Cleaning

Fingerprints, dust, or soil on the surface of the disc could cause the player to skip. For routine cleaning, wipe the playing surface with a clean, soft cloth from the center of the disc to the outer edge. If the surface is heavily soiled, dampen a clean, soft cloth in a solution of mild neutral detergent before cleaning the disc.

Monitor Function Overview





① **POWER**
- Press PWR button to turn on or off the unit.

② **SRC**
- Press SRC button to switch the display source. DVD / AV IN1 / AV IN2

③ **MUTE**
- Press MUTE button to disable or enable audio output.

④ **IR Transmitter and Receiver**
The receiving angle is about 30 degrees and the receiving distance is about 2M.

⑤ **PREV** ⏮
- Press PREV button to skip backward. (chapter).

⑥ **NEXT** ⏭
- Press NEXT button to skip forward. (chapter).

⑦ **PLAY / PAUSE** ⏯
- Press once to start playing. Press twice to pause playing.

⑧ **USB Port**
⑨ **AV Input** (Game Port)
⑩ **MS / MMC / SD Card Slot**

⑪ **Switch**
- Press this button to open the disc cover.

⑫ **Disc Tray**
(DVD / DVD-R / DVD-RW / DVD+ R / DVD+ RW / VCD / CD-ROM / CD-RW)

⑬ **Disc Cover**

Getting Started

When Using the Remote Control

The first time when you use the remote control, please remove the plastic tape before using.



Battery Replacement

1. Opening the battery case.
   Pull out the battery tray.

2. Replace the battery. (CR-2025)
   Put the battery in the case with the (+) indication upward as show in the illustration.

· Battery type : Mercury Battery - CR 2025.
· Placing a battery in backwards may cause a malfunction.

3. Closing the cover.
   Push the battery tray as illustrated until a click is heard.



Warning

Do not operate any function that takes your attention away from safely driving your vehicle.
Any function that requires your prolonged attention should only be performed after coming to a complete stop. Always stop the vehicle in a safe location before performing these functions. Failure to do so may result in an accident.

Remote Control Function Overview

Caution

- Point the remote control at the IR Reciver within 2 meters.
- It may not be possible to operate the remote control if the remote control sensor is exposed to direct sunlight or interfere with objects.
- The remote control is a small, lightweight precision device. To avoid damage, short battery life, operational errors and poor response, observe the following.
  - Do not subject the remote control to excessive shock.
  - Do not put in a trouser pocket.
  - Keep away from food, moisture and dirt.
  - Do not place in direct sunshine.
- Remove the battery if itís not being used for a long time.
- Batteries contain chemical substance, so they should be disposed of properly.



1	⏻	**Power**	Switch monitor power ON/OFF
2	OSD	**OSD Menu**	Enter or exit on-screen display menu system.
3	⏏	**Function**	Switch Number / Function mode.
4	F/R	**FM Modulator (Option)**	(1) Press Once : Switch FM ON/OFF. (87.7MHz to 88.9MHz)
		IR Sensor	(2) Press Twice : Switch IR ON/OFF.
5	USB/DVD	**USB / DVD**	Switch DVD / USB / Memory Card mode.
6	SOURCE	**Display Source**	Switch display source. (DVD→AV IN1→AV IN2)
7	■	**Stop Playback**	(1) Press Once: PRE-STOP disc playback. (2) Press Twice : STOP playback completely.
8	SETUP	**DVD Setup Menu**	Enter or exit the disc DVD setup menu.
9	MENU	**Disc Menu**	Return to disc contents menu. (For VCD with PBC feature, PBC must be turned off.)
10	▲ ▼ ⏮ ⏭	**Cursor Buttons**	Move between the function items in the menu.
11	⏮ ⏭	**Skip Backward / Forward**	Skip to the previous or next chapter / title / track.
12	▶/⏸ ENTER	**Play/Pause/Enter**	(1) Press Once : Start playback. (2) Press Twice : Pause playback.
13	SUB.	**Subtitle**	Select desired subtitle to display.
14	AUDIO	**Audio**	Select desired audio language to display.
15	◀◀ ▶▶	**Search Backward / Forward**	Select desired search backward / forward speed. ▶▶ 2X → ▶▶ 4X → ▶▶ 8X → ▶▶ 16X → ▶▶ 32X → ▶ ◀◀ 2X → ◀◀ 4X → ◀◀ 8X → ◀◀ 16X → ◀◀ 32X → ▶
16	RPT.	**Repeat**	Select desired repeat mode. (1) DVD Disc : Chapter → Title → All→Repeat Off (2) CD/ VCD Disc : Repeat 1 → Repeat All → Repeat Off
17	MUTE	**Mute**	Disable or enable audio output.
18	VOL+ VOL–	**Volume Increase / Decrease**	Increase / Decrease volume.
19	0 ~ 9	**Number Key Pad**	Press ⏏ to switch number key pad to input data for disc.
	RETURN (1)	**Return (1)**	Returns to the previous display.
	DIMMER (2)	**Dimmer (2)**	Select different LCD panel back-light brightness.
	SLOW (3)	**Slow (3)**	Select different slow playback modes for a VCD/DVD. ▶ 1/2 → ▶ 1/4 → ▶ 1/8 → ▶ 1/16 → ◀ 1/2 → ◀ 1/4 → ◀ 1/8 → ◀ 1/16 → ▶
	ZOOM (4)	**Zoom (4)**	Enlarge a picture or active image on the screen. 2X → 3X → 4X → 1/2 → 1/3 → 1/4 → ▶
	A-B (5)	**A-B (5)**	Repeat playback of a specific section within a chapter of DVD or a track.
	RANDOM (6)	**Random (6)**	Select to playback the chapter / track randomly.
	TITLE (7)	**Title (7)**	Go to disc title.
	DISPLAY (8)	**Display (8)**	Display current information during playback. ※JPEG: Change the browsing effects during playback.
	ANGLE (9)	**Angle (9)**	Select desired viewing angle. (If a DVD disc contains multi-angle feature, viewing angles may be selected.)

Before Using the MMD

Before using the MMD, please remove the card from the Multi Media Driver (MMD).



Turning Power ON/ OF

1. Press ⏻ to turn ON.
2. To turn off the power, press and hold ⏻ again.

Placing Discs

1. Turn on the power before placing discs.
2. Place the disc with the label side facing you. Once the disc is partially placed, it is drawn in automatically. Playback starts.

- *Be sure to put DVD in to the mortise, to ensure the normal operation of the DVD.*
- *If wrong disc, upside-down disc or dirty disc have been inserted. îNO DISCî is displayed.*

Switching Source

1. Press ì**SRC**î to cycle through the different sources.

DVD → AV IN1 → AV IN2

- *OSD (On Screen Display) will be turned off automatically, when not operating more than 10 seconds.*

FM/IR (On/Off)

FM ON/OFF (Option)

1. Press F/R once: To turn ON/OFF the FM transmitter.
2. When you turn on the FM, press ⏮ or ⏭ to select desired FM frequency **87.7MHz ~ 88.9MHz or OFF.**

IR ON/OFF

1. Press F/R twice: To turn ON/OFF the IR.
2. When you turn on the IR, press ⏮ or ⏭ to select ON or OFF.

Adjusting OSD

Visual brightness, contrast and color are adjustable.

- *Each source is independently adjustable.*
- *Make adjustments within 6 seconds, otherwise the OSD (On Screen Display) will turn off automatically.*

Adjusting Brightness

1. Press OSD to select **Brightness.**
2. Press ⏮ or ⏭ to adjust the brightness. Brightness can be adjusted from -20 (MIN) to + 20 (MAX).

Brightness 00

Adjusting Contrast

1. Press OSD to select **Contrast.**
2. Press ⏮ or ⏭ to adjust the contrast. Contrast can be adjusted from -20 (LOW) to + 20 (HIGH).

Contrast 00

Adjusting Color Density

1. Press OSD to select **Color.**
2. Press ⏮ or ⏭ to adjust the color density. Change depth can be adjusted from -20 (MIN) to + 20 (R MAX).

Color 00

Adjusting Hue

1. Press OSD to select **Hue.**
2. Press ⏮ or ⏭ to adjust the hue. Hue tone can be adjusted from -20 (G MIN) to + 20 (G MAX).

Hue 00

Resetting Picture Adjustment

1. Press OSD to select **Reset.**
2. Press ⏮ or ⏭ to resetting adjustment. Reset will be set up in 00(median). To save adjustment or wait 10 seconds until OSD disappear, the adjustment will be save automatically.

Reset

Caution

- Not all function will operate for every DVD. See the individual MMDís instructions for details on the features supported.
- Fingerprints on a disc may adversely affect playback. If a problem occurs, remove the disc and check for fingerprints on the playback side. Clean the disc if necessary.
- When using the remote control, be careful to press 1 button at time. Pressing multiple buttons at the same time may cause erroneous operation.
- If you switch the power or ignition key OFF during playback, playback will continue where you left off when you resume playback.
- If you try to perform an invalid operation (based on the type of disc being played), the message ì ✋ î will be displayed on the monitor screen.
- A disc type must match the setting of the system. If a wrong type disc is inserted, the message ìNO DISCî will be displayed, and playback is not available.

Playing DVD/VCD/CD

Place a disc with the label side facing up

To load discs, see ìPlacing Discî on page 7. Playback starts.

- The reverse side of a disc will not be played automatically. Remove the disc, turn it over and replace it.
- It may take some time before playback starts after placing a disc.

Disc Auto Play

The disc will play automatically without pressing ►/II when disc is placed.

MMD Menu

1. Press Menu to display MMD Menu.
2. Press ▲ ▼ ⏮ ⏭ to select the desired item, then press ►/II Enter to confirm a selection.

- For some discs it is possible to select items directly from the menu screen using the number keys (“0” to “9”).

MMD Menu

1. Press Menu to display Video Menu.
2. Press ▲ ▼ to select the desired item, and then press ►/II Enter again to confirm a selection.

Stopping Playback (PRE-STOP)

1. Press ■ during playback.ì ■ PRESS PLAY KEY TO CONTINUEî is displayed, and playback pauses.
   That position is stored in memory.
2. Press ►/II Enter in the PRE-STOP mode to return to normal playback.
   Playback starts from the position at which it was stopped.

- For some disc, the position at which playback was stopped may not be accurate.

Stopping Playback

1. Press ■ twice during playback.
   “■î is displayed, and playback stops.
2. Press ►/II Enter in the STOP mode to return to normal playback.
   Playback starts from the beginning.

Playing Still Frames (Pause)

1. During playback, press ►/II Enter to pause.
   “II î is displayed.
2. Press ►/II Enter again to resume playback.

- No sound appears during the still mode.
- The image or sound may stop temporarily when playback starts from the pause mode. This is not a malfunction.

Fast-forwarding/Fast-reversing

1. During playback, press and hold ◀◀ or ▶▶ to set search speed (◊ 2/◊ 4/◊ 8/x16/x32) forwarded or reversed.

▶▶ ▶▶ 2X→ ▶▶ 4X→ ▶▶ 8X→ ▶▶ 16X→ ▶▶ 32X→ ►

◀◀ ◀◀ 2X→ ◀◀ 4X→ ◀◀ 8X→ ◀◀ 16X→ ◀◀ 32X→ ►

2. Release ◀◀ or ▶▶ to pause, then press ►/II Enter return to normal playback.

- No sound appears during fast-forward / fast-reverse.
- Fast-forwarding / fast-reversing of a video CD is only function if the disc incorporates playback control.
- For DVD and video CD's with playback control, the menu screen may reappear during fast-forwarding / fast-reversing.

MMD Operations

Finding the Beginning of Chapters

During playback, press ⏮ or ⏭ to find the beginning of chapters.

The chapter / track switches each time the button is pressed, and playback of the selected chapter / track starts.

⏮ Press this to start playback from the beginning of the current chapter or track.

⏭ Press this to start playback from the beginning of the following chapter or track.

· *Some DVDs do not have chapters.*

※ Supplementary explanation:
ì **Chaptersî** are divisions of movies or musical selections on DVDs.
ì **Tracksî** are divisions of movies or musical selections on video and music CDs.

Setting DIMMER

Dimmer allows you to select different LCD backlight brightness during playback.

1. Press (2) **DIMMER** to turn the Dimmer function ON / OFF.

Slow Motion Playback

Slow allows you to select different slow playback modes for a VCD / DVD during playback.

1. Press (3) **SLOW** to select slow playback speed from normal to Ω, ¼, ⅛, 1/16.

⏵ ½ → ⏵ ¼ → ⏵ ⅛ → ⏵ 1/16 →

⏴ ½ → ⏴ ¼ → ⏴ ⅛ → ⏴ 1/16 → ⏵

2. To return to normal playback, press (3) **SLOW** repeatedly until normal speed playback.

· *No sound is played during slow motion playback / reverse slow motion playback.*

Setting Zoom In / Out

Zooming allows you to enlarge a picture or active image on screen during playback.

1. Press (4) **ZOOM** repeatedly to zoom in out on the playback video image.

2X → 3X → 4X→ ½ → ⅓ → ¼ → ⏵

2. To return to normal playback, press (4) **ZOOM** repeatedly until ì ZOOM OFFî

Repeating Display Period (A-B)

Use this function to set a display period repeatedly.

1. During playback, press (5) **A-B**.

Repeat A- -Setting a display period start.
Repeat A-B -Setting a display period end.
Repeat Off -Canceling the setting of display period.

Setting RANDOM (On/Off)

Random allows you to select to play the chapter / track randomly during playback.

1. Press (6) **RANDOM** to turn the Random function ON or OFF.

Switching Angle (DVD only)

On DVDs in which scenes have been filmed from multiple angles, the angles can be switched during playback.

1. During playback, press (9) **ANGLE**.
The angle switches between the angles recorded on the disc, each time the button is pressed.

· *Sometimes may be required for the angle to change.*

Using Number Key pad

1. Press ⏏ function key to switch Number/Function mode.

2. In Number mode, inputs the numeric keys (0~ 9) data for disc.



③ **FUNCTION KEY**

⑲ **NUMBER KEY PAD**

Displaying Disc Status

Use the procedure described below to display the status (title number, chapter number, etc.) of the currently playing DVD/VCD/CD on the monitor screen.

1. During playback, press 8 **DISPLAY**.
The playback status is displayed.

DVD Disc





VCD / CD Disc





Switching Subtitles (DVD only)

With multiple subtitle language DVDs, the subtitle language can be switched during playback, or subtitles can be hidden.

1. During playback, press SUB. .

The subtitle switched between the languages recorded on the disc and OFF each time the button is pressed.

- *There may be a delay before the selected subtitle appears.*
- *Not all disc with allow changing the subtitles during playback. In these cases, select subtitles from the MMDís menu.*
- *The selected subtitle language becomes the default setting every time the power is turned on or the disc is replaced. If the disc does not include that language, the discís default language is selected instead.*
- *For some discs, the subtitles will be displayed even when this is set to off.*

Switching Audio Tracks

DVDs can have different audio tracks. These alternate tracks can be switched during playback.

1. During playback, press AUDIO.
The sound switched between the alternate audio tracks recorded on the disc each time the button is pressed.

- *The selected alternate track becomes the default setting every time the power is turned on or the disc is replaced. If the disc does not Include that track, the discís default language is selected instead.*
- *Not all discs will allow changing the alternate audio tracks during playback. In these cases, select audio tracks from the DVD menu.*
- *There may be a delay before the selected alternate track begins to play.*

Video CDs With multiplex audio



Chapter/Track/ Title Repeat Playback

Use this function to play the discís titles, chapters or tracks repeatedly.

1. During playback, press RPT. .
The repeat mode switches each time when the button is pressed.

DVD Disc



CD/VCD Disc



USB Operations

CAUTION

- Not all function will operate for every formats. See the individual USBís instructions for details on the features supported.
- Do not use USB while driving your vehicle. Always stop the vehicle in a safe location before performing these functions. Failure to do so may result in serious injury or an accident.
- If you try to perform an invalid operation (based on the type of disc being played), the message ì ✋ î will be displayed on the monitor screen.
- A disc type must match the setting of the system. If a wrong type disc is inserted, the message ì NOT FOUND USBî will be displayed, and playback is not available.

Switching DVD/USB/Memory Card Mode

After connecting USB or Memory Card, the unit shall search the directories automatically, and show all files on the screen.

1. Press USB/DVD to change to USB mode or Memory Card mode.
2. Press ▲ ▼ to select desired files or press ⏮ ⏭ to skip to the next and previous page, and then press ►/II ENTER to start or pause playback.

- *It may take some time to search the directories while reading the USB or Memory Card.*

3. Press ■ to return to the playback menu.



Setting RANDOM

Random allows you to select to play the track randomly during playback.

1. During placyback, press 6 **RANDOM**. The random mode switches each time when the button is pressed.

MP3

Random → Folder

AVI

Single → Repeat One → Repeat All → Repeat Off

Repeating Playback

Use this function to play the tracks in USB or Memory Card repeatedly.

1. During playback, press RPT.. The repeat mode switches each time when the button is pressed.

MP3

SINGLE → REPEAT ONE → REPEAT FOLDER → FOLDER

AVI

SINGLE → REPEAT ONE → REPEAT ALL → REPEAT OFF

Tips

When play photos, you can see the photos in the Photo Preview Area.

1. Press ►/II ENTER to start or pause playback by full-screen automatically.
2. During playback, press ▲ or ▼ see previous or next photo.
3. Press ⏮ or ⏭ , the photo can rotate clockwise or counterclockwise.
4. Press ■ to return to index of the photos.



- Press ▲ ▼ ⏮ ⏭ to select desired photos, and press ►/II ENTER to start or pause playback.
- Press **MENU** to return to the playback menu.

DVD Setup Operation

The following steps 1 to 2 are common to each of the DVD settings described here. Refer to each section for details.

1. Press and hold SETUP on the remote control. The setup menu appears on the monitor.

2. Press ⏮ or ⏭ to select desired setting item (General Setup Page / Password Setup Page / Preference Page), then press ▼.

Further items will be displayed.

GENERAL SETUP PAGE
TV DISPLAY / OSD LANGUAGE / SCREEN SAVER / LAST MEMORY

PASSWORD SETUP PAGE
PASSWORD MODE / PASSWORD

PRFERENCE PAGE
TV TYPE / AUDIO / SUBTITLE / DISC MENU / PARENTAL / DEFAULT

EXIT SETUP PAGE

3. Press ▲ or ▼ to change the setting of further items, then press ►/II ENTER.

4. Press and hold ►/II ENTER. The settings are stored and the setup mode is deactivated.

5. Press SETUP or ìEXIT SETUPî to return to normal display.

· *When settings are changed, old settings are overwritten. Make a note of current settings before making changes. If the vehicleís battery is disconnected, the settings will be cleared and will return to Factory settings.*

General Setup Page

TV display, OSD language, Screen savre and Last-memory are adjustable.

1. Press SETUP button on the remote control. The setup menu appears on the monitor.

2. Press ▲ or ▼ to select TV DISPLAY / OSD LANGUAGE / SCREEN SAVER / LAST MEMORY, then press ►/II ENTER to confirm a selection.

Setting TV Display (default: Wide)

· *For some discs, the picture may not be set to the selected screen size.*

3. Press ▲ or ▼ to select desired screen type.

4. Press ►/II ENTER to save adjustment.



· **Normal / PS (Pan-Scan)**
Select this when connected to a conventional 4:3 size monitor. The picture will fill the entire TV screen. Due to the mismatch in aspect ratio, parts of the movie at the extreme left and right sides will not be visible when playing a 16:9 size movie.

· **Normal / LB (Letter Box)**
Select this when connected to a conventional 4:3 size (normal TV aspect ratio) monitor. There may be black bands visible at the top and bottom of the screen when playing a 16:9 size movie.

· **Wide (16:9)**
Select this when connected to a wide screen TV. This is selected upon shipment from the factory.

MMD Setup

Setting OSD Language (default: English)

3. Press ▲ or ▼ to select desired language.

· *There are 9 kinds of languages can be chosen. (English, French, Spanish, German, Italian, Portuguese and ...)*

4. Press ENTER to save adjustment.
The settings are stored and the setup mode is deactivated.



Setting Screen Saver (default: On)

3. Press ▲ or ▼ to select screen saver ON or OFF.

4. Press ENTER to save adjustment.



Setting Last Memory (default: On)

Video memory can choose to manually ON or OFF.

3. Press ▲ or ▼ to select last memory ON or OFF.

4. Press ENTER to save adjustment.



Password Setup Page

There is not original password.

1. Press SETUP button on the remote control. The setup menu appears on the monitor.

2. Press ⏮ or ⏭ to select Password Setup Page.

3. Press ⏭ to select Change, then press ⏏
Function key + Number key pad (0~ 9) to setup password and press ìOKî button to save adjustment.





Preference Setup

TV type, Audio, Subtitle, Disc Menu and Parental are adjustable.

1. Press SETUP button on the remote control. The setup menu appears on the monitor.
2. Press ⏮ or ⏭ to select Preference Setup.
3. Press ▲ or ▼ to select TY TYPE / AUDIO / SUBTITLE / DISC MENU / PARENTAL / DEFAULT, then press ►/II ENTER to confirm a selection.

Setting TV Type (default: NTSC)

Broadcast TV System can be manually switched.

4. Press ▲ or ▼ to select PAL / AUTO / NTSC.
5. Press ►/II ENTER to save adjustment.



Setting Audio Language (default: English)

4. Press ▲ or ▼ to select desired audio language.
5. Press ►/II ENTER to save adjustment.



Setting Subtitle Language (default: Off)

4. Press ▲ or ▼ to select desired subtitle language or OFF.
5. Press ►/II ENTER to save adjustment.



Setting Disc Menu Language (default: English)

4. Press ▲ or ▼ to select desired disc menu language.
5. Press ►/II ENTER to save adjustment.



Setting Parental (default: 8 Adult)

4. Press ▲ or ▼ to select a rating level between 1 to 8.

· The are 8 kinds of levels can be chosen. (Kid saf, G, PG, PG13, PGR, R, NC17, Adult)

5. Press ►/II ENTER to save adjustment.


- - Preference Page - -
TV Type AUTO 1 KID SAF
Audio ENG 2 G
Subtitle OFF 3 PG
Disc Menu ENG 4 PG 13
Parental 5 PGR
Default 6 R
7 NC 17
8 ADULT
Set Parental Control

Setting Default

Use this function to restore Factory system setting.

4. Select RESET to change to Factory setting.
5. Press ►/II ENTER to save adjustment.



Installation and Connections

Before installing or connecting the unit, please read the following and page 2~ 3 of this manual thoroughly for proper use.

Caution

The back seat passenger must fasten the safety belt before operating the unit.

Limitation

· The width between the front seats must be greater that the width of the monitor.
◎ 8″ LCD Monitor → 22cm

· The chink between the front seat and center console box must be greater than the thickness of the bracket arms (At least 1.5cm) .

· The top cover of the Center console box should be operated. We propose that the transverse axle must be higher than the top cover by 3-5 cm.

· Both sides of the brackets should not go beyond the case edge of Center console box and too near to driver.

Have the wiring and installation done by experts.
The wiring and installation of this unit requires special technical skill and experience. To ensure safety, always contact the dealer where you purchased this unit to have the work done.

Use specified accessory parts and install them securely.
Be sure to use only the specified accessory parts. Use of other than designated parts may damage this unit internally or may not securely install the unit in place. This may cause parts to become loose resulting in hazards or product failure.

Arrange the wiring so it is not crimped or pinched by a sharp metal edge.
Route the cables and wiring away from moving parts (like the seat rails), sharp or pointed edges. This will prevent crimping and damage to the wiring. If wiring passes through a hole in metal, use a rubber grommet to prevent the wires insulation from being cut by the metal edge of the hole.

Drilling can cause airborne debris.
Airborne debris can cause serious injury to the eyes. Wear protective eye-wear when drilling.

Warning

Make the correct connections.
Failure to make the proper connections may result in fire or product damage.

Use only in cars with A 12 volt negative ground.
(Check with your dealer if you are not sure.) Failure to do so may result in electric shock or injury due to electrical shorts.

Do not allow cables to become entangled in surrounding objects.
Arrange wiring and cables in compliance with the manual to prevent obstructions when driving.

Do not splice into electrical cables.
Never cut away cable insulation to supply power to other equipment. Doing so will exceed the current carrying capacity of the wire and result in fire or electric shock.

Do not damage the electrical wire when drilling holes.
When drilling holes in the console box for installation, takes precautions so as not to contact, damage the electrical wiring. Failure to take such precautions may result in fire.

Keep small objects as batteries out of the reach of small children.
Swallowing them may result in serious injury.
If swallowed, consult a physician immediately.

Precautions:

Be sure to disconnect the cable from the (-) battery post before installing this unit.
This will reduce any chance of damage to the unit in case of a short-circuit.

Be sure to connect the color coded leads according to the diagram.
Incorrect connections may cause the unit to malfunction or damage to the vehicle's electrical system.

When making connections to the vehicle's electrical system, be aware of the factory installed components. Do not tap into these leads to provide power for this unit.
Failure to do so may result in damage to the unit or vehicle. When it doubt, please consult your dealer.

This unit uses female RCA-type jacks for connection to other units (e.g. amplifier) having RCA connectors.
You may need an adaptor to connect other units. If so, please contact your authorized dealer for assistance.

Parts Indication

① LCD Monitor
② Open Cover DVD Player
③ Signal Cable (blue)
④ Outside Cover Of Transverse Axle
⑤ Signal Cable (black)
⑥ Antenna
⑦ Transverse Axle
⑧ Outside Cover Of Right (left) Bracket
⑨ Plastic Washer
⑩ Mounting Plate



Installation and Connections

Caution:

The back seat passenger must fasten the safety belt before operating the unit.

Limitation

● The width between the front seats must be greater than the width of the monitor.
8" LCD Monitor ⟶ 22cm

● The space between the front seat and center console box must be greater than the thickness of the bracket arms (At least 1.5cm).



● Both sides of the brackets should not go beyond the cases edge of the center console box and not to close to the driver.

● When you install the bracket, please make sure the height of the left and right bracket should be the same, and vertical with the transverse axle.

● To ensure the top cover of the console box can be operated, the transverse axle must be higher than the top cover of console box 3~5cm distance..



Caution:

- Please use the shape of the console and the position of the folded monitor to determine the angle and position of the bracket installation
- When the monitor is folded, it should be parallel to the front of the console box, and keep distance more than 1cm.(Figure B)

Vertical Installation:

If the shape of console box is similar to Figure A, please make sure the bracket and top cover of console box is 90 degrees, then continue to install.



Figure A

Oblique Installation:

If the shape of the console box is similar to Figure B, then let the bracket and incline of console box stay parallel, then continue to install.

● Before installation, please ensure the monitor will not touch the car mats when it's folded down.



Figure B



Installation Step

1 Measure the width and height of the console box first.
※For example:
The console box is 15(W) x 25(H) cm. (Figure 1)



(Figure 1)

2 Adjust the width of the transverse axle.
※For example:
The width of the console box is 15cm. (Figure 1)

According to the width of the Center Console Box, pull out and adjust the suitable width of the transverse axle. (Figure 2)


(Figure 2)

3 Choose a suitable Plastic Washer.
Check both sides of the center console, if it has a slope, please choose a suitable plastic washer (the thick oblique washer/ thin oblique washer/ flat washer) and make the brackets perpendicular to 90 degrees. (Figure 3)



(Figure 3)

4 Mark the screw positions of the disc holder.
After you decided on the installation angle of the brackets please mark the screw positions of the disc holder on both sides of console box. (Figure 4)
After that, drill four 4Φ holes in the both side of console box.


(Figure 4)


(Figure 3-2)

Installation and Connections

5 Installation of screws:

· A Type (Figure 5-1)
Put the mounting plate inside of the console box, and fix the mounting plate from outside to inside with 4pcs 4x25 self-tapping screws. same as right bracket.

· B Type (Figure 5-2)
Use 4x25 self-tapping screws and spring buckle to fix the bracket on the both sides of the console box.

A Type



(Figure 5-1)

6 Drill cable hole.

After you have chosen the suitable plastic washer, please drill a 15mm hole with the plastic washer in the U breach place. (Figure 6)



15mm Cable Hole

(Figure 6)

B Type



(Figure 5-2)

7 Fix the transverse axle.

After adjusting and confirming the width of transverse axle, please use the Allen Key to tighten the 5x12 screws. (Figure 7)



(Figure 7)

8 Assemble the outside cover of the Right/ Left Brackets.

Use 3x8 screws to fix the outside cover of the right and left bracket arms. (Figure 8)

The above shows all the installation procedure.



(Figure 8)

Connections

AV Connectors



Green / Yellow

Video Input Connector
This connector is used in combination with the video inputs of other video products (AV head out or TV Tuner).

White(L)
Red (R)

Audio Input Connectors
These connectors are used in combination with a head unit or TV Tuner with audio output connectors.

Blue / Yellow

Video Output Connector
This connector is used in combination with the video inputs of other video products (AV head unit or LCD monitor).

Brown / White(L)
Yellow / Red (R)

Audio Output Connectors
These connectors are used in combination with a head unit or LCD monitor with audio input connectors.

Black

GND
Connect this line to the vehicleís GND line.

Red

ACC
Connect this line to the vehicleís ACC line. (Switched 12V, ignition)

CAUTION

The factory default will have a connector. Please cut the connector before connect to the system.



Installation and Connections

System Connections



Accessories

■ Screen

x1

■ Bracket Arm



x1

■ Outside Covers Of Bracket

x2

■ Screws (F⊕3x8)
- For Outside covers of Bracket

x4

■ Plastic Washers
① Thick oblique washer x2
② Thin oblique washer x2
③ Flat washer x 2



x6

■ Allen Key



x1

■ Remote Control

x1

■ User Manual

x1

■ Signal Cable



x1

■ AV2 Cable



x1

■ Rubber Plugs

x4

■ Rubber Bars



x2

A Type

■ Mounting Plates

x2

■ Screws (F⊕4x25)
- For Mounting Plates

x8

B Type

■ Spring Buckles

x8

■ Self-tapping Screws (F⊕4x25)
- For Spring Buckles

x8

General Specifications

DISPLAY SCREEN

Size	8 inch
Aspect Ratio	16:10
LCD-Type	Digital type TFT Liquid CrystalDisplay
DVD Loader System	Open Cover (Made in China)
Number of Elements	800(W)x480(H)x3
Effective Number of Elements	99.9% or more
Back Light	LED Lamp

GENERAL

Operating Voltage	10 - 16VDC (Typical: 12 V)
Power Consumption	1.2 A (MAX) 0.82 A(TYP) 0.08A (Stand by)
Video Input	1.0V p-p 75
Video Output	1.0V p-p 75
Audio Input	2.0V rms (MAX)
Audio Output	2.0V rms (MAX)
IR Transmitter	CH A:2.3MHz/2.8MHz
FM Transmitter Modulator (Option)	87.7MHz-88.9MHz Frequency (Wireless)
Operating Temperature	32∘F to + 122∘F (0∘C to + 50∘C)

MONITOR

Size	8 inch
Width	213mm
Depth	154mm
Height	34mm
Weight	0.78 Kg

UNIVERSAL BRACKET

Bracket Type	D Type
Width	150~ 260mm
Heigh	12mm
Depth	255mm
Weight	0.50kg

Note:
- Specifications and the design are subject to modification without notice due to improvements in technology.
- Some figures and illustrations on this manual may be different from your product.

Troubleshooting

⚠ CAUTION

If you encounter a problem, please turn the power off, then on again. If the unit still no function normally, please review the items in the following checklist. This guide will help you isolate the problem if the unit is at fault. Otherwise, make sure the rest of your system is properly connected or consult your authorized dealer.

No function or display.

Vehicleís ignition off.
- If connected following the instructions, the unit will not operate with the vehicles ignition off.

Improper power lead connections.
- Check if the power lead is properly connected.

No fuse or blown fuse.
- Replace the fuse on the battery lead of the unit with the proper value.

Vehicleís battery is weak.
- Check the voltage of vehicleís battery.

Disc playback sound is wavering.

Moisture condensation in the disc unit.
- Allow enough time for the condensation to evaporate (about 1 hour).

Unable to fast-forward or fast-reverse the disc.

The disc has been damaged.
- Eject the disc and discard it. Using a damaged disc in your unit can cause damage to the mechanism.

Disc playback sound skips due to vibration.

Improper mounting of the unit.
- Securely re-mount the unit.

The disc is very dirty.
- Clean the disc

The disc has scratches.
- Change the disc.

The pick-up lens is dirty.
-Do not use a commercial available lens cleaner disc. Consult your nearest dealer.

Disc playback sound skips without vibration.

Dirty or scratched disc.
- Clean the disc. Damaged disc should be replaced.

CD-R/CD-RW playback is not possible.

Close session (finalization) has not been performed.
- Perform finalization and attempt playback again.

Unit does not operate.

Monitorís power is not turned on.
- Turn on the monitor power.

Condensation
-Wait a while (about 1 hour) for the condensation to dry.

No picture is display.

Monitorís mode is not switched to the mode you want to see.
- Switch to the mode you want to see.

Monitorís parking break cord is not connected.
- Connect the monitor parking brake cord and set the parking break. (For details, refer to the monitor instruction.)

Brightness control is set for minimum brightness control.
- Adjust the brightness.

Incorrect setting of the mode.
- Switch to the correct mode.
- Check the connection to the source unit.
- Check the power of the source unit.

Incorrect or open connection with the Monitor, AV interface unit.
- Check the connection and remedy.

Playback does not start.

Disc is loaded upside-down.
- Check the disc and load it with the label side facing you.

The disc is dirty.
- Clean the disc.

A disc not able to playback with this unit is loaded.
- Check if the disc is able to be played back.

Parental lock is set.
- Cancel the parental lock or change the rating level.

Setup menu is displayed.

- Press SETUP to turn the menu off.

Image stops sometimes.

Disc is scratched.
- Replace with an non-scratched disc.

Picture color is poor.

Brightness/Contrast/Color controls are not set to the proper positions.
- Check each control.

Picture was very dark when starting the machine.

The temperature is too low.
- Wait a while (about 1 hour) for the warm up. After that, the monitor will return to the normal condition.

Information

Picture is unclear or noisy.

Disc is being fast-forwarded or fast-reversed.
- The picture may be unclear, but this is normal.

Vehicleís battery power is weak.
- Check the battery power and wiring. (The unit may malfunction if the battery power is under 11 volts with a load applied.)

Monitorís fluorescent tube is worn out.
- Replace the monitor fluorescent tube.

Image stops sometimes.

Disc is scratched.
- Replace with a non-scratched disc.

The remote control does not work.

IR Received range is not enough.
- The remote control can be used within 2 meters.

Something interfere the IR transmitter.
- Please remove any possible objects.

Battery is exhausted.
- Replace the remote control battery.

Spots or dotted lines-stipes appear.

The LCD panel is manufactured using an extremely high precision manufacturing technology.
- Its effective pixel ratio is over 99.99%. This means that 0.01% of the pixels could be either always ON or OFF.

Caused by neon signs, high-voltage power lines, CB transmitter, other vehicleís ignition plugs, etc.
- Change the location of your vehicle.

⚠ Caution

Due to continuous product improvement, specifications and design are subject to change without notice.

Warranty

⚠ Caution:

- Please make sure to read the user manual carefully.
- Please make sure the unit has a serial number before you send the unit back to be repaire. If the unit does not have a serial number or the serial number
- has been removed Vizualogic will not be able to fix the unit under warranty.

- Warranty void if seal is broken or removed.

Warranty period 90 Days:

From the date of original retail purchase.
Vizualogic will offer a full replacement warranty.

Vizualogic will not replace the product if there is physical damage or customer abuse to the unit.

Out of the Warranty period:

- If the unit fails Vizualogic will, for a fee, inspect and offer to repair any failed component.
- Prior to repairs Authorization for cost will be extended to customers.
  Customer must return to Vizualogic.
  Customer will pay all freight costs.

Extended Warranty available at extra cost If the product was installed at or before the vehicle was purchased.

Please consult your Vizualogic dealer for more detailed information on purchasing a Extended Warranty.

Other:

When sending the product for repair, please pack the product perfectly, so as to prevent damage again on the way of transport. Thanks.

Warranty Card

Under normal usage, if the product is out of order, please inquire your authorized retail shop.

If you need any product serviced, please present this warranty card for certification.

Please remember to ask for the authentication seal from your authorized retail shop.

If the authentication seal is incorrect Vizualogic will not replace the unit under warranty.

Caution:
- Please test all Functions Before Installing
- Please record the serial number of your unit. In the space provided below. The serial number plate is located on the back of the monitor.
- If the units didn't have a serial number or it is missing we will be unable to offer a warranty.

Caution:
In order to guarantee your rights, please remember to fill in the retail shop name, address and telephone number correctly after purchasing the product.

Item	Elite Center Console Monitor	Warranty period
Model	Elite Console	From the date of original retail purchasing
Bracket Type	D Type	
Color	☐ Black	
Serial number	(This is necessary.)	
Purchasing Date	(YY /MM /DD)	

User data	User Name		Tel.	
	Address			
Retailer data	Shop Name		Tel.	
	Address			
Retailerís Seal		Selling date: (This is necessary.)		